

## FAQ FOR TBIH BREAK-OVER WRENCHES

**Q1: What fastening applications are preset wrenches used in?**

**A1:** Preset torque wrenches are ideal for fastening applications where operators repeatedly assemble parts at the same torque setting.



**Q2: Does the TBIH wrench have an external torque scale or adjustment mechanism?**

**A2:** A preset wrench doesn't have an external torque adjustment scale. These tools have an internal torque adjustment mechanism for setting the torque value using a hex key and a torque analyzer.

**Q3. How do you set the torque for the preset wrench?**

**A3.** It can be preset using a torque analyzer. Or you can order the tool at a preset torque value.

**Q4. Can the preset torque value be changed for a new fastening application?**

**A4.** Yes, the wrench can be internally adjusted and calibrated to a new preset torque value. It would require a torque analyzer or the tool being sent to the calibration lab.

**Q5. What is the ISO standard for recalibrating hand wrenches?**

**A5.** ISO 6789-1:2017 calls for a maximum of 5,000 before recalibration.

**Q6. What is the difference between the TB and TBIH wrench models**

**A6.** The TB wrench comes with a head permanently attached to it. It is not removable. The TBIH break-over wrench allows you to remove the wrench head and add another option.

**Q7. Can the TBIH only be calibrated in CW & CCW directions?**

**A7.** The TBIH is calibrated in the CW direction only.

**Q8. Is the TBIH compatible with different types of wrench heads and sizes?**

**A8.** Yes, the TBIH features an Interchangeable end-fitting design. You can select head types and sizes (options vary per each model)

**Q9. Does Mountz offer the capability to produce custom-size heads for application?**

**A9.** Yes, Mountz does produce custom-size heads.